

### Arista:

7000 Series 2 RU  
 DCS-7050SX-64  
 7160-48YC6  
 DCS-7010T-48-F  
 DCS-7050SX3  
 Arista 7368-CH  
 7050SX3-48YC8

### Alcatel

OS6850-24X

### Brocade:

300  
 ICX 7750  
 MLXe-16

### Cisco:

WS-C2960S-24TD-L  
 WS-C3750-24PS-S  
 WS-C3750G-12S-S  
 WS-X4640-CSFP-E  
 WS-C3560E-24TD-S  
 ME-3600X-24FS-M  
 ME-3400-24FS-A  
 WS-C6506-E  
 N3K-C3064PQ-10GE  
 N3K-3172PQ-10GE  
 N9K-C93180YC-FX  
 Nexus 5596UP  
 Nexus 9396PX  
 Nexus 3064  
 Nexus 3048  
 Nexus 9372TX  
 ASR 9006  
 891F Router  
 NCS5501

### Ciena

5160  
 6500

### Dell:

N4032

### Extreme:

X670  
 X620-10X

### H3C:

S12504X  
 S5560  
 S6800  
 LS-9820-8C  
 S9820-64H  
 S2126-EI  
 S3110-26TP-SI  
 S5120-28C-EI  
 S6820-56HF  
 S6850-56HF  
 S5500-28F-EI-D  
 SR8803-X-S  
 S5820V2-52QF  
 S9825 Series  
 S9855 Series  
 12504

### Huawei

HW 5720  
 HW S6730  
 HW S6720  
 HW 8816  
 CE6865-48S8CQ-EI  
 CE9860-4C-EI  
 CE8850-64CQ-EI  
 CE12800, CE5810, CE6855, CE6856,  
 CE6857  
 FM9860-4C-EI  
 FM8850-64CQ

### HP:

2910AL-24G  
 5900AF-48G-4XG-2QSFP+  
 ProCurve 2910al-24G

### Intel:

X520 Adapter

XXV710-DA2 Adapter

### IBM

RackSwitch G8264T

RackSwitch G8000

RackSwitch G8316

### Juniper:

MX960

EX3300-24T

EX4300-48P

QFX5100-48S

### Mellanox:

SB7700

SB7800

MSN2100

MCX4111A-ACAT Adapter

MCX413A-BCAT Adapter

MCX415A-CCAT Adapter

### Nokia:

7360FX

IXR

SAS-sx

SR

ISAM\_7360

### Transmode

TM301